

Nevada

pH108



2 type,
will ship it in random.

2 типа,
Будут отправлены в
случайном порядке.

~ Caractéristiques Principales ~

Affichage: LCD Numérique

Précision: 0.01

Résolution: 0.01

Température de fonctionnement: 0 ~ 60 ° c

Gamme de mesure: 0.00 ~ 14.00

Source d'alimentation: 2x1.5 V (pile bouton LR44)

ma

Tel: 0531068245



How to use



1. Remove the protecting cap
2. Rinse the electrode with distilled water and dry with filter paper
3. Turn the ph meter ON by pressing the ON/Off key



4. Immerse the pH meter electrode in the solution to be tested



5. Stir gently and wait for the reading to stabilize

How to calibration

1



1. Turn on PH meter

2

6.86 pH Buffer Powder



2. Dissolve each buffer solution in 250ML of distilled water

3



3. Immerse the electrode into the PH 6.86 solution, (under the temperature of 25)

4



4. Press the "CAL" (calibration) button for 5 seconds and release
-Display will start flashing 6.86